




Fig. 6

ASSEMBLY, FRONT VIEW





Fig. 8

CAN FEED ASSEMBLY, SHOWING FEED STAR BRACKET;
TOPPER AND FEED DISC.



COVER FEED ARM ASSEMBLY WITH COVER TRIP PARTS

Fig. 10



A 275



A 432



5178



31417



31418




5171




5152



A 274




26763



27691



104 B 301



26357

Fig. 28

HIDDEN PARTS FOR 24-291 (CANCO 4 ROLL)
HEAD DRIVING MECHANISM





Fig. 24

Showing (at right) the Safety Device which prevents breakage of
Feed Parts should a cover become jammed.



CAN LIFTER

Showing Can Lifter photographed in machine, with Lifter Front and Rear Plates, Lifter Housing, Upper and Lower Caps, and Front Guide Removed.
(Change part numbers shown are for No. 307 (3-7/16" dia. cans).)

Fig. 22




Fig. 30

SEAMING HEAD UNIT